9.7 TM ASSY-S


12
1
SRVA
CN7004
Lubricating oil
(GYA1001)
10
5
Cleaning liquid (GEM1004)
Cleaning paper (GED-008)
3
8
9
7
4
6
SPCN
CN6102
2
8
4
11
11
13

TM ASSY-S PARTS LIST

Mark	No.	Description	Part No.
NSP	1	Stepping Motor (SK)	DXM1227
NSP	2	Spindle Motor G11 (N)	DXM1231
NSP	3	05SD Pickup Assy R	OWY8075
NSP	4	Adjust Screw	DBA1263
NSP	5	Skew Spring (SWPB)	DBH1437
NSP	6	Joint Spring (J)	DBK1261
NSP	7	Slider Spring G11 (J)	DBK1262
NSP	8	Guide Shaft (S)	DLA1918
	9	Joint	DNK3858
NSP	10	Mounting Plate G11 (J)	DNK4307
	11	Tapping Screw 04	VBA1092
	12	Screw	BPZ20P080FTC
	13	Screw	BPZ26P080FTC